


**JUST LIGHT.**

## Removal instruction

997607

Instructions on how light sources and separate control gears can be removed without being permanently damaged for verification purposes by market surveillance authorities:

An Instruction on how to remove the light source from a containing product is provided for reference:



The removal may only be carried out by a professional.

Step 1: Clamp out the wire buckle of the transformer wire and remove the screw connecting the transformer end with a screwdriver.



Step 2: Pull out the transparent plate, take care of the LEDs during this step, do not touch them.



Step 3: Use an electric soldering iron to remove the wires from the circuit board, please protect the LEDs and do not touch the LEDs.



Step 4: Remove the light source from the board.

