



# KARTEN



PL

INSTRUKCJA MONTAŻU  
INSTRUKCJA OBSŁUGI

GB

ASSEMBLY INSTRUCTIONS  
INSTRUCTION MANUAL

D

MONTAGEANLEITUNG  
BEDIENUNGSANLEITUNG

NL

HANDLEIDING VOOR DE MONTAGE  
GEBRUIKSAANWIJZING

TR

MONTAJ TALIMATI  
KULLANIM KLAVUZU

RU

ИНСТРУКЦИЯ ПО МОНТАЖУ  
ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ

RO

INSTRUCȚIUNI DE INSTALARE  
INSTRUCȚIUNI DE UTILIZARE

IT

ISTRUZIONI DI MONTAGGIO  
MANUALE DI ISTRUZIONI

FR

NOTICE DE MONTAGE  
MANUEL INSTRUCTIONS

SK





















MONTÁŽNY NÁVOD  
NÁVOD NA POUŽITIE










HU






SZERELÉSI ÚTMUTATÁS  
KEZELÉSI UTASÍTÁS







CZ





MONTÁŽNÍ NÁVOD  
NÁVOD K POUŽITÍ

1 (60)	1(60)TV(aku) / 1(60)TVe	1(80)TVBB(aku)/ 1(80)TVBBe	BAR(1)ŠC
			
1(80)TVL(aku)/1(80)TVLe	1(80)TVP(aku)/1(80)TVPe	BAR(1)LC	BAR(1)PC
			
1 (80) BB	1 (80) L	1 (80) P	1 (80)
			
1D (10) L	1D (10) P	1D (10f) SL	1D (10f) SP
			
1D (10) SL	1D (10) SP	EN(2tv)L / EN(2tv)P	EN(2)L / EN(2)P
			


2(150)FL	2(150)FP	2(150)FBB	DOST(40)SL
			
DOST(40)SP	DOST(80)SL	DOST(80)SP	TBS(80)
			
1(80)TV(aku) / 1(80)TVe			
			









13




12



14



15



16

