
















Instalation manual

LAHTI: KOM_1D5S_80




Element symbol	Dimensions			Code	Package
	1108	395	16		
1	1108	395	16	L-105	1/1
2	830	400	16/32/32	L-202	1/1
3	350	110	16	L-502	1/1
4	390	60	16	L-405	1/1
5	350	110	16	L-501	1/1
6	390	60	16	L-406	1/1
7	796	60	16	L-407	1/1
8	796	60	16	L-408	1/1
9	333	110	16	L-504	1/1
10	796	371	16	L-303	1/1
11	390	365	16	L-304	1/1
12	347	348	3	L-605	1/1
13	1048	371	16	L-106	1/1
14	1108	395	16	L-107	1/1
15	1073	408	3	L-604	1/1
16	1006	392	16	L-004	2/2
17	390	170	16	L-005	2/2







3



4




1




2


7




8




5




6






! a=b



11



12

