

INSIDE















SYSTEM MINI BOX WYSOKI SZKŁO ANTRACYT

40





60









80









ZESTAWIENIE AKCESORIÓW NIEZBEDNYCH DO MONTAŻU

A-027  11	A-031  4	A-352/1  2	A-352/2  2	A-352/3  2	A-352/4  1	A-352/5  1
A-352/6  2	A-352/7  2	A-352/8  2	A-352/9  2	A-352/10  2	A-352/11  2	A-352/12  3,5 x 12 mm 4


Niektóre akcesoria pakowane są po kilka sztuk więcej niż wynika to z zestawienia.
Podczas montażu prosimy postępować zgodnie z instrukcją.








1





2

L




3

L




4


L




5 **L**




6




7




60 cm
40 cm




80 cm




8




9




10



11



12



13

