



# SWING



10min



Warning | **Achtung** | Attention | **Uwaga** | **Attenzione** | **Advertencia** | **Atenção**

For indoor use only | **Nur für Verwendung im Inneren** | Pour utilisation en interieur | **Do użytku wewnętrznego** | Utilizzo per uso interno | **Para utilización en interiores** | Produto apenas de uso interno

Keep the product away from heat sources | **Das Produkt von Hitzequellen entfernt aufbewahren** | Garder le produit éloigné des sources de chaleurs | **Trzymać produkt z dala od źródeł ciepła** | Tenere il prodotto lontano da fonti di calore | **Mantener el producto plejado de las fuentes de calor** | Guardar o produto afastado das fontes de calor

For safety reasons, the product cannot be removed from its cover | **Aus Sicherheitsgründen kann dieses Produkt nicht abgezogen werden** | Pour des raisons de sécurité, le produit n'est pas déhoussable | **Z powodów bezpieczeństwa, z produktu nie można zdjąć pokrowca** | Per ragioni di sicurezza, il prodotto non è sfoderabile | **Por razones de seguridad, el producto no es desfundable** | Por razões de segurança, a capa do produto não é amovível

Do not climb on this product | **Nicht auf dieses Produkt steigen** | Ne montez pas sur ce produit | **Nie wspinać się na produkt** | Non salire sul prodotto | **No suba sobre este products** | Não subir para cima deste